


OWNER'S MANUAL



DEEP CYCLE BATTERIES

BLUETOOTH GUIDE

Download the Application for your Phone:



(Bluetooth Available in Select Models, see the Specification Tables 4A -4C in this manual, Pages 16 &17)







Link Device

Click to pair your battery to your device.

Page two




Battery Dashboard

Displays all of your basic battery information

Page three



Monitor Usage



Page four



System Information

Log History of any unusual battery activity

Page five



Contact Us

Customer Service Place an Orde r

Need Assistance? Please contact customer service at 704-360-9311 or ionicbatteries.com

BLUETOOTH GUIDE

Page two menu







Settings

Access additional battery settings and information Login

Password: 0000 "ZERO" Rename Device

Customize your battery name



Battery information page

HV = High Voltage (Over-Charge)

Charger voltage too high LV = Low Voltage (Over-Discharge)

Application voltage too low

LTD = Low Temp Discharge

Battery used (discharged) below operating temperature range LTC = Low Temp Charge

Battery charged below freezing (may damage with HC)



OCC = Over Current Charge

Charger current too high OCD = Over Current Discharge

Application current too low

HTD = High Temp Discharge

Battery overheated while in use HTC = High Temp Charge

Battery overheated while charging

Indicator Status

= Good

= Error

Cell Voltage

Used to ensure cell voltage balanced Take action if you have error code. Exift battery code shows too hot, disconnect and allow it to cool.

Need Assistance? Please contact customer service at 704-360-9311 or ionicbatteries.com