

A - ON/OFF SWITCH B - ON/OFF/ON SWITCH C - OFF/1/2/BOTH SWITCH



